

www.Kama-Labs.com

(Assembly instructions and latest firmware you can find on my website)

YULIA v6

Assembled my own hands 😊

Thanks for purchase!!!

Features:

- * 6x **IV-11/IV-12** Russian VFD tubes (made in 1990-93)
- * 2 IV-1 or IV-8 VFD separators (show am/pm and on/off of alarm)
 - * 32bit STM32F100C8 processor
 - * 15 parameters
 - * 20 years lifetime of tubes
 - * 12/24 hours mode
 - * 1 Alarm
 - * Port for external devices
- * Fade at night (increase lifetime of tubes in twice!)
 - * Turn off leading zero
 - * 2 fonts for "6", "7" and "9" digits
 - * Smooth PCB routing
- * Countdown timer 99days:23hour:59mins:59sec
 - * Full remote control
 - * USB connection to PC (for update firmware)
- * Double Multicolour led glow (independent random color leds and **RGB** leds under each tube)
 - * Adjustable brightness of **RGB** and AUTO leds
- * **RGB** led (6 colors of backlight or autochange color mode)
 - * 10 modes of switch digits
 - * 2 modes of separator tubes
- * **IV-11/IV-12** tubes works in static mode

* Thermometer

- * Correction of temperature
- * C or F temperature format
- * Accurate to +/- 1 minute/year
- * Setup of clock accuracy
- * Date in format DD.MM.YY or MM.DD.YY or YY.MM.DD
- * Backup battery. Data is not lost when power off
- * Power source - DC 5V barrel plug 5.5mm/2.1mm ("+" inside, "-" outside)
- * Consuming current – 500 - 1000mA
- * Height of pcb with elements only 13 mm
- * Noiseless work

Dimensions of the clock - 178mm(W) x 51mm(L) x 65mm(H)

Dimensions of the clock in case - 222mm(W) x 85mm(L) x 85mm(H)

No	Settings	Value
1	12/24 time format	0 - 12h time format 1 - 24h time format
2	Hi.Hour tube fading	0 - disable fading 1 - enable
3	Show time mode	0 - simple mode 1 - constructor 2 - constructor №2 3 - smooth mode 4 - smooth + random mode 5 - smooth + random mode №2 6 - wave 7 - fading 8 - shift 9 - run 10 - up-down 11 - up-down №2 12 - binary clock 13 - all effects one by one
4	Backlight mode	0 - all leds off 1..5 - brightness 6 - AUTO brightness 7 - AUTO brightness + turn off leds in the dark

5	Show current temperature	0 - disable 1 - every 2 minutes 2 - every 5 minutes																				
6	Work of separators	0 - disable 1 - work together 2 - work alternately																				
7	Show current date	0 - off 1 - every 2 minutes 2 - every 5 minutes																				
8	Correction of temperature coefficient	0 .. 9 Current temp. - temp.coeff. = real temperature <table><tr><th>Temp.coeff</th><th>Current temp.</th></tr><tr><td>0</td><td>0</td></tr><tr><td>1</td><td>-1</td></tr><tr><td>.</td><td>.</td></tr><tr><td>.</td><td>..</td></tr><tr><td>10</td><td>-10</td></tr><tr><td>11</td><td>+1</td></tr><tr><td>.</td><td>.</td></tr><tr><td>.</td><td>.</td></tr><tr><td>19</td><td>+10</td></tr></table>	Temp.coeff	Current temp.	0	0	1	-1	10	-10	11	+1	19	+10
Temp.coeff	Current temp.																					
0	0																					
1	-1																					
.	.																					
.	..																					
10	-10																					
11	+1																					
.	.																					
.	.																					
19	+10																					
9	Clock accuracy correction	0 .. 9 Bigger value - slowly clock																				
10	Date format	0 - DD.MM.YY 1 - MM.DD.YY 2 - YY.MM.DD																				
11	Temperature format	0 - Celsius 1 - Fahrenheit																				
12	Brightness of BOTTOM backlight	0 .. 6																				
13	Brightness of tubes	0 .. 3 4 - automatic brightness																				
14	Font type for “6”, “7” and “9” digits	0 - type 0 1 - type 1																				
15	Turn off at night	0 - Off 1 - On																				
16	Work of separators in Night mode	0 - disable 1 - work together 2 - work alternately																				

How to use remote control

Button	Action
OK	Enter/exit in parameters mode
◀ ▶	Next effect of switch digits / next value
▲ ▼	Change value / tube brightness
1	Time setup
2	Alarm setup
3	Date setup
4	Show temperature
5	Show date
6	On/off alarm
7	Countdown timer setup
8	Turn off LEDs and tubes
9	Change brightness of bottom LEDs
*	Change brightness of top LEDs
#	Change color of top LEDs
▲	Change brightness of tubes

- Use ◀ ▶ for change position in setup modes
- For change value you can use ▲ ▼ or use any number buttons

How to set time or alarm


- 1) Press 1 key on remote for enter in time setup and 1 key for enter in alarm setup.

* Note: in time setup current time shows in 24h format only

- 2) Set hours
- 3) Press ▶ key for go to minutes setting
- 4) Press ▶ key again for set seconds
- 6) Seconds will reset to "00" if you will press ▲ key
- 7) Press ▶ key for exit from setting time mode



How to change settings

- 1) Press **OK** for enter into menu
- 2) You will see number of parameter (1) and value of parameter (0):

- 3) Press **▲ ▼** for changing value
- 4) Press **◀ ▶** for switch parameter
- 5) Press **OK** for exit.

How to set current date

- 1) Press **3** key
- 2) You will see date in DD.MM.YY format
- 3) Use **▲ ▼** for changing value or use any number buttons
- 4) Press **◀ ▶** for switch position

How to change color of LEDs and brightness

Press ***** key to change brightness of top LEDs and **#** key to change color. 3 times flashing means that color will change slowly and automatically.

9 key will change brightness of bottom leds. You can't change their color.

How to set countdown timer

Press **7** key to enter in timer setup. You will see latest value of timer in DD:HH:MM time format. To change time format press **▶** key. Right indicator (2) will ON when time format DD:HH:MM and OFF when HH:MM:SS.

Indicator (1) show activity of timer. Press **OK** key to activate timer, (1) indicator will ON.


(1) (2)

To set timer time, press **# key** and set DD, then HH, MM and SS. Use **▶ key** to go for next value.

When timer active you can press **7 key** to exit from timer setup. Timer will continue work.

Remote control in timer mode:

Button	Action
OK	On/off timer
▶	DD:HH:MM / HH:MM:SS
◀	Reset to previous timer value
#	Timer setup
7	Exit

How to make HARD RESET if something wrong

When your clock starts, you will see firmware version. Something like: **11 04 19**

If you will press **OK key** in this moment, clock will reset all your setting. You will hear p-i-i-i-i-i-p p-i-p p-i-p. That's mean HARD RESET is done.

How to set night fading

Set 15th parameter to 1 and press **# key**. You will enter into setup. You will hear b-i-i-i-p and will see:

00 : __ : __

Now, you need set time of START and STOP fading.

Example: you go to sleep at 11:10PM and get up 6:30AM. So, you need to set START time as 23:10 and STOP time as 6:30.

